




AOC-S100G-b2C



User's Guide

Revision 1.0

The information in this user's guide has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, and makes no commitment to update or to keep current the information in this user's guide, or to notify any person or organization of the updates. **Please Note: For the most up-to-date version of this user's guide, please see our Website at www.supermicro.com.**

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this user's guide at any time and without notice. This product, including software and documentation, is the property of Supermicro and/or its licensors, and is supplied only under a license. Any use or reproduction of this product is not allowed, except as expressly permitted by the terms of said license.

IN NO EVENT WILL SUPER MICRO COMPUTER, INC. BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPER MICRO COMPUTER, INC. SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between the manufacturer and the customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Supermicro's total liability for all claims will not exceed the price paid for the hardware product.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in an industrial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instruction manual, may cause harmful interference with radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate".



WARNING: This product can expose you to chemicals including lead, known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

User's Guide Revision 1.0

Release Date: August 5, 2020

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2020 by Super Micro Computer, Inc.
All rights reserved.

Printed in the United States of America

Preface

About this User's Guide

This user's guide is written for system integrators, IT professionals, and knowledgeable end users. It provides information for the installation and use of the AOC-S100G-b2C add-on card.

An Important Note to the User

All graphic images and layout drawings shown in this user's guide are based upon the latest PCB revision available at the time of publishing of this user's guide. The add-on card you have received may or may not look exactly the same as the graphics shown in this user's guide.

Returning Merchandise for Service

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service will be rendered. You can obtain service by calling your vendor for a Returned Merchandise Authorization (RMA) number. When returning to the manufacturer, the RMA number should be prominently displayed on the outside of the shipping carton and mailed prepaid or hand-carried. Shipping and handling charges will be applied for all orders that must be mailed when service is complete.

For faster service, RMA authorizations may be requested online (<http://www.supermicro.com/support/rma/>).

This warranty only covers normal consumer use and does not cover damages incurred in shipping or from failure due to the alteration, misuse, abuse or improper maintenance of products.

During the warranty period, contact your distributor first for any product problems.

Conventions Used in the User's Guide

Pay special attention to the following symbols for proper system installation:

Warning: Important information given to ensure proper system installation and to avoid possible damage done to the components or injury to yourself.



Note: Additional information given for proper system setup.

Important Links

For your system to work properly, please follow the links below to download all necessary drivers/utilities and the user's manual for your server.

- Supermicro product manuals: <http://www.supermicro.com/support/manuals/>
- Product drivers and utilities: <http://www.supermicro.com/wftp>
- Product safety info:
http://www.supermicro.com/about/policies/safety_information.cfm
- If you have any questions, please contact our support team at: support@supermicro.com

This manual may be periodically updated without notice. Please check the Supermicro website for possible updates to the manual revision level.

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000

Fax: +1 (408) 503-8008

Email: marketing@supermicro.com (General Information)
support@supermicro.com (Technical Support)

Web Site: www.supermicro.com

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390

Fax: +31 (0) 73-6416525

Email: sales@supermicro.nl (General Information)
support@supermicro.nl (Technical Support)
rma@supermicro.nl (Customer Support)

Web Site: www.supermicro.nl

Asia-Pacific

Address: Super Micro Computer, Inc.
3F, No. 150, Jian 1st Rd.
Zhonghe Dist., New Taipei City 235
Taiwan (R.O.C)

Tel: +886-(2) 8226-3990

Fax: +886-(2) 8226-3992

Email: support@supermicro.com.tw

Web Site: www.supermicro.com.tw

Table of Contents

Preface

About this User's Guide	3
An Important Note to the User	3
Returning Merchandise for Service	3
Conventions Used in the User's Guide	3
Important Links	4
Contacting Supermicro	5

Chapter 1 Introduction

1-1 Overview	1-1
1-2 About this Add-on Card	1-1
1-3 Key Features	1-1
1-4 Additional Features	1-2
1-5 Supported Platforms	1-6

Chapter 2 Hardware Components

2-1 Add-On Card Image and Layout	2-1
2-2 Major Onboard Components	2-2
2-3 QSFP28 Ethernet Connections	2-3
QSFP28 Port	2-3
2-4 NC-SI Header & PCI-E 4.0 x16 Connector	2-4
NC-SI Header	2-4
PCI-E 4.0 x16 Connector	2-4
2-5 Jumper Settings	2-5
Explanation of Jumpers	2-5

Chapter 3 Installation

3-1 Static-Sensitive Devices	3-1
Precautions	3-1
3-2 Before Installation	3-2
3-3 Installing the Add-on Card	3-2
3-4 Installing Drivers (for Broadcom®BCM57508)	3-3
Before Installing the Drivers for the Linux Operating System Only	3-3
Installing 100G Drivers for the Linux Operating System	3-3
Installing 100G Drivers for the Windows Operating System	3-4

Chapter 1

Introduction

1-1 Overview

Congratulations on purchasing your add-on card from an acknowledged leader in the industry. Supermicro products are designed with the utmost attention to detail to provide you with the highest standards in quality and performance.

1-2 About this Add-on Card

The Supermicro AOC-S100G-b2C is the most advanced Network-Controller Sideband Interface (NC-SI) Ethernet LAN card on the market today. This add-on card provides unprecedented network interface connectivity with the Broadcom® BCM57508 Controller.

Featuring Asset Management for Supermicro system and server platforms, this add-on card supports the TruFlow™ Technology, SR-IOV, multi-queueing, stateless offloads, network overlay, NIC partitioning, and RDMA over Converged Ethernet (RoCE). The AOC-S100G-b2C offers high-performance connectivity and superb remote sideband manageability to meet the growing needs of high-end computing platforms. For more information regarding product support or updates, please refer to our website at <https://www.supermicro.com/en/products/accessories/addon/AOC-S100G-b2C.php>.

1-3 Key Features

The key features of this add-on card include the following:

- Standard PCI-E Gen 4.0 x16 host interface
- Low profile, standard short-length form factor
- TruFlow™ (Flow-processing engine integrated to reduce CPU overhead)
- SR-IOV with up to 128 VFs
- Low latency
- NC-SI for IPMI Support

- Stateless offloads
- RoCE (RDMA over Converged Ethernet)
- Network overlay: VXLAN and NVGR
- NPAR (NIC partitioning)
- Dual QSFP28 connectors
- PXE support
- Asset management (for Supermicro systems only)
- RoHS support
- Cable support: copper cables, fiber cables, optic cables with optional transceivers
- Dimensions 6.6in (L) x 2.713in (W)

1-4 Additional Features

Host Interface

- PCI Express x16, x8, x4, x2, x1 lane configuration
- Interface up to four PCIe hosts
- Function Level Reset (FLR)
- Message Signal Interrupt (MSI-X)
- Advanced Error Reporting (AER)
- Transaction Processing Hints (TPH)

Network Features

- Jumbo frames (up to 9600 bytes)
- IEEE 802.3x flow control
- Link Aggregation (IEEE 802.3ad)

- Virtual LANs — IEEE 802.1q VLAN tagging

Performance Features

- Low-chip latency < 1 μ s TX and RX combined
- Maximum 100 million packets per second

Stateless Offload Features

- TCP, UDP, IP checksum offloads
- Large Send Offload (LSO)
- Receive Segment Coalescing (RSCO)
- TCP Segmentation Offload (TSO)
- Generic Receive Offload (GRO)
- Receive Side Scaling (RSS)
- Transmit Side Scaling (TSS)
- Accelerated Receive Flow Steering (aRFS)
- Header-Payload Split

NIC Partitioning:

- 16 physical functions
- Bandwidth allocation per partition
- Partitioning control via sideband communication
- Up to 64 MAC/VLAN filters per partition
- Per partition statistics support
- Stateless offloads configuration per partition
- Software teaming support for partition

Virtualization

- NetQueue, NDIS VMQ, and MultiQueue

- PCIe SIG SR-IOV compliant
- Edge Virtual Bridging (EVB) — VEB/VEPA support
- Support for 1K Virtual Functions (VFs)
- VxLAN-aware stateless offloads
- NVGRE-aware stateless offloads
- Geneve-aware stateless offloads
- IP-in-IP-aware stateless offloads
- GRE-aware stateless offloads
- Per Virtual Function (VF) statistics
- VF Receive-Side Scaling (RSS)/Transmit-Side Scaling (TSS)
- VF isolation, source pruning, and anti-spoofing

RDMA over Converging Ethernet (RoCE)

- RoCEv2 and RoCEv1
- Congestion control
- Reliable Connection (RC), Unreliable Datagram (UD), and Raw EtherType
- 1 million RC queue pairs
- 64 K shared receive queues
- 1 million completion queues
- 1 million memory regions and windows
- 1 million protection domains
- Fast memory registration
- OFED 3.18-2 and 4.8-1
- Network Direct Kernel Provider Interface (NDKPI) 2.0

- Network Direct Service Provider Interface (NDSPI) 2.0

Flow Processing

- Exact match flow lookup
- Wildcard match flow lookup
- Flexible key selection
- Packet recycling
- Connection tracking
- VLAN insertion/deletion
- NAT/NAPT
- Tunnel encapsulation/decapsulation
- Custom tunnel processing
- Flow tracking and aging
- Mirroring
- Metering
- Flow counters/statistics

Data Center Bridging

- Priority-based flow control (PFC IEEE 802.1Qbb)
- Enhanced transmission selection (ETS IEEE 802.1Qbb)
- Data center bridging capability eXchange (DCBX IEEE 802.1Qbb)
- Up to eight traffic classes per port; fully DCB compliant per IEEE 802.1Qbb)

Manageability

- Network Controller Sideband Interface (NC-SI) over RMII Based Transport (RBT)

Operating Conditions

- Operating temperature: 0°C to 55°C (32°F to 131°F)

- Storage temperature: -40°C to 70°C (-40°F to 158°F)
- Storage humidity: 90% non-condensing relative humidity at 35°C

1-5 Supported Platforms

The AOC-S100G-b2c supports:

- Supermicro® motherboards with minimum PCI-E x16 expansion slots
- Supermicro® server systems with low-profile or full-height PCI-E 4.0 x 16 expansion slot
- NC-SI feature is only supported by Supermicro motherboards with corresponding NC-SI connectors



Note: This product is intended to be used with Supermicro server systems or motherboards as an integrated solution package.

Chapter 2

Hardware Components

2-1 Add-On Card Image and Layout




Figure 1




Figure 2

2-2 Major Onboard Components

AOC-S100G-b2C Major Components	
No	Component Name
1	JNCSI1: NCSI header
2	JP1: 1-2 (default): SMBUS ARP mode, 2-3: Static SMBUS address mode
3	JP4: 1-2 (default): Disable STBY Mode, 2-3: Enable STBY Mode
4	QSFP28: Quad Small Form-Factor Pluggable 28
5	QSFP28: Quad Small Form-Factor Pluggable 28
6	LED4: QFSP28 Port 1 Link/Active LED
7	LED5: QFSP28 Port 2 Link/Active LED
8	JGF1: PCI-E 4.0 x16
9	BCM57508: Broadcom



Note: Please consult with Supermicro before enabling JP4.


2-3 QSFP28 Ethernet Connections

QSFP28 Port

A Quad-Small-Form-Factor-Pluggable 28 (QSFP28) connector is located at J2/J3 on the add-on card. The QSFP28 ports operate at up to 100Gb/s. Plug the Direct Attached Copper (DAC) cable into the QSFP28 ports for network connections. See the layout below for the location.

1. QSFP28

2. QSFP28



2-4 NC-SI Header & PCI-E 4.0 x16 Connector


NC-SI Header

A Network-Controller Sideband Interface (NC-SI) header is located at JNCSI1 on the add-on card. Connect an appropriate cable from this header to a motherboard to provide an out-of-band (sideband) connection between the onboard Baseboard Management Controller (BMC) and a Network Interface Controller (NIC) for remote management. For the network sideband interface to work properly, you will need to use a motherboard that supports NC-SI and also need to have a special cable. Please contact Supermicro at www.supermicro.com to purchase the cable for this header. See the layout below for the location of the JNCSI1 header.

PCI-E 4.0 x16 Connector

A PCI-E 4.0 x16 connector is located at JGF1 on the add-on card. Insert this connector into a PCI-E 4.0 x16 slot on a motherboard to use this add-on card. See the layout below for the location.


1. [NS-CI Header](#)
2. [PCI-E 4.0 x16 Connector](#)




2-5 Jumper Settings


Explanation of Jumpers

To modify the operation of the motherboard, jumpers can be used to choose between optional settings. Jumpers create shorts between two pins to change the function of the connector. Pin 1 is identified with a square solder pad on the printed circuit board. See the motherboard layout pages for jumper locations.



 **Note:** JP1 is for production use only.

JP4 for NC-SI Standby by Power	IPMI Support	FailOver Support	WoL Support	Function	Notes
Disable = No standby Power to AOC NIC	Yes	Yes	No	Disable jumper to disconnect the standby power	Default
Enable = Standby Power to AOC NIC	Yes	Yes	Yes	Enable jumper to connect standby power to AOC NIC	WoL is supported but limited to platforms with sufficient air-flow when it is in standby mode (S5 state). Please consult Supermicro before enabling it.



1. JP1
2. JP4

Chapter 3

Installation



Note: Your system came with the AOC-S100G-b2C add-on card which is designed as a part of an integrated solution. We do not recommend that any part of your system components be removed and re-installed. However, if you do need to remove or re-install a system component, including this add-on card, please follow the instructions below to ensure proper system setup. Also, be sure to remove the power cord first before adding, removing or changing any hardware components to avoid damaging the system or components.

3-1 Static-Sensitive Devices

Electrostatic Discharge (ESD) can damage electronic components. To avoid damaging your add-on card, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

Precautions

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing the add-on card from the antistatic bag.
- Handle the add-on card by its edges only; do not touch its components, or peripheral chips.
- Put the add-on card back into the antistatic bags when not in use.
- For grounding purposes, make sure that your system chassis provides excellent conductivity between the power supply, the case, the mounting fasteners and the add-on card.

3-2 Before Installation

To install the add-on card properly, be sure to follow the instructions below.

1. Power down the system.
2. Remove the power cord from the wall socket.
3. Use industry-standard anti-static equipment (such as gloves or wrist strap) and follow the instructions listed on page 3-1 to avoid damage caused by ESD.
4. Familiarize yourself with the server, motherboard, and/or chassis documentation.
5. Confirm that your operating system includes the latest updates and hotfixes.


3-3 Installing the Add-on Card

Follow the steps below to install the add-on card into your system.

1. Remove the server cover and, if necessary, set aside any screws for later use.
2. Remove the add-on card slot cover. If the case requires a screw, place the screw aside for later use.
3. Position the add-on card in the slot directly over the connector on the motherboard, and gently push down on both sides of the card until it slides into the PCI connector.
4. Secure the add-on card/motherboard to the chassis. If required, use the screw that you previously removed.
5. Attach any necessary external cables to the add-on card.
6. Replace the chassis cover.
7. Plug the power cord into the wall socket, and power up the system.

3-4 Installing Drivers (for Broadcom®BCM57508)

To install drivers for the AOC-S100G-b2C add-on card for either Linux and Windows, please follow the instructions below.



Before Installing the Drivers for the Linux Operating System Only

Infiniband-diags is a set of utilities designed to help configure, debug, and maintain infiniband fabrics. Installing them from the Linux library is necessary prior to driver installation. To do so, please first download the following libraries:

```
yum -y install libibverbs* infiniband-diags perftest qperf
librdmacm-utils
```

```
yum -y groupinstall "InfiniBand Support"
```

Installing 100G Drivers for the Linux Operating System

Follow the steps below to install the drivers on the Linux operating system:

1. Download the Linux driver package file: `nextxtreme-bnxt_en-<ver>.tar.gz`.



Note: This driver can be found on either the Supermicro website or by going to the Linux_Driver directory from the FTP site (ftp://ftp.supermicro.com/Networking_Drivers) or CDR-NIC LAN driver CD in the following directory: Broadcom > 100G > Linux > Linux_Driver.

2. Install the driver by entering the following commands

```
tar xvzf netextreme-bnxt_en-<ver>.tar.gz
cd netextreme-bnxt_en-<ver>
make build
make install
```

RDMA over Converged Ethernet (RoCE) is a network protocol that allows remote direct memory access (RDMA) over an Ethernet network. This feature is optional, but if you would like to install with RoCE, please follow the additional steps below:

1. Download the Linux driver package file: libbnxt_re-<ver>.tar.gz.



Note: This driver can be found on either the Supermicro website or by going to the RoCE_Lib directory from the FTP site (ftp://ftp.supermicro.com/Networking_Drivers) or CDR-NIC LAN driver CD in the following directory: Broadcom > 100G > Linux > RoCE_Lib.

2. Install the library by entering the following commands:

```
tar xvzf libbnxt_re-<ver>.tar.gz
cd libbnxt_re-<ver>
./configure
make
make install
cp bnxt_re.driver/etc/libibverbs.d
echo "/usr/local/lib">>etc/ld.so.conf
ldconfig -v
```

Installing 100G Drivers for the Windows Operating System

Follow the steps below to install the drivers on the Windows operating system:

1. From the FTP site or CDR-NIC LAN driver CD, go to the following directory:
Broadcom > 100G > Windows.
2. Choose the desired Windows driver package folder.
3. As the drivers are in .inf format, you can install the driver from the Device Manager.

(Disclaimer Continued)

The products sold by Supermicro are not intended for and will not be used in life support systems, medical equipment, nuclear facilities or systems, aircraft, aircraft devices, aircraft/emergency communication devices or other critical systems whose failure to perform be reasonably expected to result in significant injury or loss of life or catastrophic property damage. Accordingly, Supermicro disclaims any and all liability, and should buyer use or sell such products for use in such ultra-hazardous applications, it does so entirely at its own risk. Furthermore, buyer agrees to fully indemnify, defend and hold Supermicro harmless for and against any and all claims, demands, actions, litigation, and proceedings of any kind arising out of or related to such ultra-hazardous use or sale.