

# L-Vote

## Confidea FLEX Voting License




### Description

Confidea FLEX is Televic's all-in-one tabletop conference unit. To unlock the different functionalities, you need to activate the correct license. **L-Vote** is the license to activate electronic voting on the unit.


With the Confidea FLEX, voting is independent of the hardware, offering extensive voting options.

Easily manage the licenses on the unit itself in initialization mode. The unit gives a clear overview of the active licenses and the number of remaining licenses. Activating and deactivating licenses is as simple as pressing the button of the desired license.




With the Confidea FLEX, voting is **independent of the hardware**, offering extensive voting options when the voting license is active. The interface of the unit shows all available voting options and meeting participants can cast their votes by pressing the buttons on the interface.

The content and the options available on the voting screen depend on the voting parameters configured in CoCon. When **voting timers** are active, the interface shows a dynamic progress bar displaying the remaining time to cast your vote. Participants can even see the voting results in real-time if the operator makes voting results visible for everyone in CoCon.



### Chairperson controls

Units configured as chairperson have additional voting controls. As chairperson you have the option to start and stop the voting session from your unit\*.



## Features

- » Voting Timer
- » Maximum of 10 options
- » Color coded voting buttons
- » See real-time and overall voting result
- » Start and stop voting session by chairperson\*

\* For the Chairperson to be able to start and stop a voting session on a Confidea FLEX unit, the L-Vote license is required.

## Software

To fully configure, manage, and use the voting options on the Confidea FLEX, Televic's Confero 360 or CoCon management software is required.

If used with Confero 360, the following standard license is required:

<b>Confero</b>	<b>71.98.3000</b>
----------------	-------------------

If used with CoCon, the following standard licenses are required:

<b>CoCon Discussion</b>	<b>71.98.1101</b>
<b>CoCon Voting</b>	<b>71.98.1104</b>

To enhance the functionality of meetings and extend the features of the Confidea FLEX, the following optional licenses are available:

<b>CoCon Signage</b>	<b>71.98.1102</b>
<b>CoCon Authentication</b>	<b>71.98.1105</b>