L-Identification

Confidea FLEX Identification License



Description

Confidea FLEX is Televic's all-in-one tabletop conference unit. To unlock the different functionalities, you need to activate the correct license. **L-Identification** is the license to enable the use of identification badges on the unit.


With the Confidea FLEX, the badge reader is always present on the unit but is only active when the Identification license is active.

Easily manage the licenses on the unit itself in **initialization mode**. The unit gives a clear overview of the active licenses and the number of remaining licenses. Activating and deactivating licenses is as simple as pressing the button of the desired license.



With the Confidea FLEX, the badge reader is always present on the unit but is only active when the Identification license is active.

Depending on the selected **delegate participation mechanism**, delegates can use their badge to identify themselves on a seat. The interface shows how to use the badge to log in and displays participant's names when assigned to a seat.





Features

- » Users identify themselves to the system using their badge
- » Animation showing how to log in
- » RFID card reader

Software

To fully configure, manage, and use the identification options on the Confidea FLEX, Televic's Confero 360 or CoCon management software is required.

If used with Confero 360, the following standard license is required:

Confero 71.98.3000

If used with CoCon, the following standard licenses are required:

CoCon Discussion 71.98.1101 CoCon Authentication 71.98.1105

To enhance the functionality of meetings and extend the features of the Confidea FLEX, the following optional licenses are available:

 CoCon Voting
 71.98.1104

 CoCon Signage
 71.98.1102