

For use with these
part numbers:

383289 383498

383322 383564

Inventory

2' (61cm)	0
3' (91cm)	0
3½' (107cm)	0
4' (122cm)	4
5' (162cm)	6
6' (183cm)	0
Stiffener	8
	4

⚠ Caution:



Beware of Pinch Points

Before assembling StageScreen:

- Spread the tarp (included)
 - Lay the viewing surface facedown on the tarp
 - Assemble the frame on top of the screen surface
 - Frame sections should be arranged so that:
 - A. Viewing surface attachment posts are on the outside of the frame
 - B. Guide pins should point CLOCKWISE
 - C. Rivcups should face UPWARD
- Red dots above indicate recommended attachment points for flying or wall bracket.

