

For use with these
part numbers:

383291 383500

383324 383566

Inventory

2' (61cm)	4
3' (91cm)	0
3½' (107cm)	2
4' (122cm)	0
5' (162cm)	4
6' (183cm)	4
Stiffener	10
	4

Caution:



Beware of Pinch Points

Before assembling StageScreen:

- Spread the tarp (included)
- Lay the viewing surface facedown on the tarp
- Assemble the frame on top of the screen surface
- Frame sections should be arranged so that:
 - A. Viewing surface attachment posts are on the outside of the frame
 - B. Guide pins should point CLOCKWISE
 - C. Rivcups should face UPWARD

- Red dots above indicate recommended attachment points for flying or wall bracket.

