


Quick Usage

1. Interface Introduction

Teams Rooms Interface


You need to switch the system to Microsoft Teams mode (For more information, please refer to [Switch Account](#)).



No.	Description
1	The local time.
2	The user name and account number.
3	Start an instant meeting.
4	Make a phone call or call someone to join the meeting.
5	Start/stop sharing.
6	Scheduled meetings and you can click Join to join the meeting directly.
7	To go to Camera Control, Mic Control, and Status.
8	Go to Give feedback, Accessibility, Restart Device, and Settings

Teams Rooms Meeting Interface

You need to switch the system to Microsoft Teams mode (For more information, please refer to [Switch Account](#)).



No.	Description
1	The local time.
2	The user name.
3	Display the current meeting name, meeting time, organizer, and more.
4	Invite someone or dial a number.
5	Display the list of participants, and you can do the operations such as muting.
6	Meeting controls toolbar.

Yealink RoomConnect Software Interface

You need to switch the system to Microsoft Teams mode (For more information, please refer to [Switch Account](#)). Open the Yealink RoomConnect application, and the software interface is as follows.

The screenshot shows the Yealink RoomConnect web interface. At the top left is the Yealink logo and 'Yealink RoomConnect' text. On the right are icons for help, settings, and window controls. The main area displays three device cards:

- AVHub:** Bind camera: 1, Firmware Version: 153.431.0.10, Hardware Version: 153.0.33.0.2.0.32, Serial Number: 806011E120000439.
- CP700:** Firmware Version: 100.420.0.45, Hardware Version: 100.1.112.0.0.0.0, Power: 100%, Serial Number: 5801219060000151. This card is highlighted with a green border and an orange box around the details, with a red circled '1' above it and a right-pointing arrow icon.
- MTouchII:** Firmware Version: 126.410.0.85, Hardware Version: 126.2.0.0.2.0.17, Serial Number: 803061E020002244.

No.	Description
1	Display basic device information, and click to enter the device details setting.
2	Basic software information and device management server configuration.

2. General Feature

When the administrator completes the [Quick Setup](#), the device can start working usually.

Description	Related Document
Start an instant meeting	Instant Meeting
Join the meeting	Join Meeting
Starting sharing via a cable	Share Content via Cable
Starting sharing via the WPP20	Share Content via WPP20
Camera control	Basic Settings