
ergotron®

LX Pro Desk Dual Direct Arm: 45-684



Equipment & Accessories Disposal

- 1. Please dispose of all batteries in accordance with local law.
- 2. All Electronics should be recycled through an electronics recycler.
- 3. Remaining plastics and metals can be recycled through a commercial recycler.

See website for more recycling information: www.ergotron.com/environment

www.ergotron.com | USA: 1-800-888-8458 | Europe: +31 (0)33-45 45 600 | China: 400-120-3051 | Japan: japansupport@ergotron.com © 2025 Ergotron, Inc. All rights reserved.