







# **MASTERLIQUID ATMOS II 240**

# **MASTERLIQUID ATMOS II 360**

**USER MANUAL**



x1

PRE-INSTALLED  
x2INTEL 1851 OFFSET BRACKET  
x1


x2

240 ATMOS II  
x8  
360 ATMOS II  
x121851/1700  
x41200/115X  
x4


x4



x4




x1



x1




x2







x1

## 02. INTEL & AMD





### 03. INTEL & AMD







## 04. INTEL - LGA 1851 / 1700 / 1200 / 115X



## 05. INTEL - LGA 1851 / 1700 / 1200 / 115X




## 06. INTEL 1851 OFFSET BRACKET







## 07. INTEL 1851 OFFSET BRACKET


NOTE: PLEASE CHECK WHETHER YOUR MOTHERBOARD IS COMPATIBLE WITH THIS OFFSET BRACKET.



## 08. INTEL 1851 OFFSET BRACKET




## 09. INTEL 1851 OFFSET BRACKET




## 10. INTEL 1851 OFFSET BRACKET

NOTE: PLEASE CHECK WHETHER YOUR MOTHERBOARD IS COMPATIBLE WITH THIS OFFSET BRACKET.




## 11. AMD SOCKET AM5 / AM4






## 12. AMD SOCKET AM5 / AM4




## 13. 240 & 360 ARGB / PWM CONNECTION



Motherboard header	Connector color
CPU_FAN	Black
AIO_PUMP	Gray


## 14. INTEL & AMD



## 15. INTERCHANGEABLE PUMP COVER

NOTE: PUMP COVER MAY VARY BY EACH VERSION.


**M**



**BASIC VERSION**

x1


**O**



**VRM FAN VERSION**

x1


**P**



**PIXEL LED VERSION**

x1


**Q**



**LCD VERSION**

x1

**R**




**PIXEL LED VERSION**


**LCD VERSION**

x1


## 16. BASIC VERSION: INFINITY MIRROR & METALLIC DESIGN




## 17. VRM FAN VERSION



## 18. VRM FAN VERSION




## 19. PIXEL LED VERSION







## 20. PIXEL LED VERSION



## 21. LCD VERSION



## 22. LCD VERSION



**EN** As a result of bubbles in the coolant, you might hear sounds coming from your cooler on the first run. Just chill out for 15 minutes and the sounds will disappear.

**AR** يوس كئيلع ام .ىلوالأ فقللا يف ذرّبملا نم اتاوصأ حمست دق ،ديربتلأ كدام يف تاعاقف دوجو ببسب تاوصألا يف تخستسو فقيقد 15 راطتنال.

**BG** Поради балончета в охладителя е възможно да чувате звуци при първото пускане. Просто изчакайте 15 минути и звуците ще изчезнат.

**CS** Při prvním spuštění se mohou z chladiče ozývat zvuky. Je to způsobeno bublinami v chladicí kapalině. Tyto zvuky po 15 minutách provozu ustanou.

**CHT** 由於冷卻液中存在氣泡，因此初次啟動時可能聽見散熱器發出聲音。這時只要靜待 15 分鐘，聲音即會消失。

**CHS** 冷却液中存有气泡，因此冷却器第一次运行时有可能发出声音。请静候15分钟，声音随后会消失。

**DE** Durch Bläschen im Kühlmittel macht Ihr Kühler bei der ersten Inbetriebnahme möglicher weise Geräusche. Warten Sie einfach 15 Minuten und die Geräusche verschwinden.

**EL** Λόγω της ύπαρξης φυσαλίδων στο ψυκτικό υγρό, ενδέχεται να ακούσετε ήχους κατά την πρώτη λειτουργία της ψύκτρας σας. Αυτοί οι ήχοι θα σταματήσουν μετά από 15 λεπτά.

**ES** Debido a las burbujas en el refrigerante, es posible que escuche sonidos procedentes de su refrigerador la primera vez que lo ponga en marcha. Simplemente, espere 15 minutos y los sonidos desaparecerán.

**FR** En raison de bulles dans le liquide de refroidissement, vous entendrez peut-être des sons provenant de votre refroidisseur à la première utilisation. Laissez simplement refroidir pendant 15 minutes pour que les sons disparaissent.

**KR** 냉각수에 거품이 있으면 최초 작동 시 쿨러에서 소리가 날 수 있습니다. 이 경우 15분 동안 냉각시키면 소리가 사라집니다.

- KZ** Салқындату сұйықтығының ішінде көпіршіктердің болуына байланысты, салқындатқышты алғаш рет қосқан кезде дыбыстар естілуі мүмкін. 15 минут бойы күтіңіз, дыбыстар басылады.
- HU** A hűtőfolyadékban levő buborékok miatt hangokat hallhat a hűtőből az első indításkor. Hagyja hűlni 15 percig és a hang megszűnik.
- ID** Dikarenakan gelembung udara di pendingin, anda mungkin akan mendengarkan suara pada pendingin yang dinyalakan pertama kali. Tunggu selama 15 menit, suara tersebut akan hilang.
- IT** Se sono presen el liquido refrigerante, al primo uso è possibile che la ventola emetta un rumore. Attendere 15 minuti e il rumore scomparirà.
- JP** 初回運転時、冷却液に含まれる泡が原因でクーラーから音が聞こえることがあります。15分ほどそのままにしておくと言は消えます。
- NL** Door luchtbellen in de koelvloeistof, hoort u bij het eerste gebruik geluiden van de koelventilator. Als u 15 minuten geduld hebt, zullen de geluiden verdwijnen.
- PL** Przy pierwszym uruchomieniu pęcherzyki powietrza w środku chłodzącym mogą powodować słyszenie dźwięków dochodzących z elementu chłodzącego. Po 15 minut dźwięki zanikną.
- PT** Na primeira utilização, poderão ser emitidos ruídos provocados pela existência de bolhas de ar no refrigerante. Aguarde um pouco, os ruídos desaparecerão após 15 minutos.
- RU** Вследствие наличия пузырьков воздуха в охлаждающей жидкости при первом использовании кулер может издавать шум. Дайте кулеру поработать 15 минут, чтобы этот шум прекратился.
- SR** Usled prisustva mehurića u rashladnoj tečnosti, moguće je da ćete pri prvom pokretanju čuti zvukove koji dopiru iz hladnjaka. Samo isključite 15 minuta i zvukovi će nestati.
- TR** Soğutucudaki kabarcıkların bir sonucu olarak, ilk çalıştırmada soğutucunuzdan çıkan sesler duyabilirsiniz. Yalnızca 15 dakika sonra sesler kesilecektir.
- UA** У результаті утворення бульбашок у хладагенті під час першого запуску можуть виникати певні звуки. Просто зачекайте 15 хвилин, і звуки зникнуть.

Please visit our website at [www.coolermaster.com](http://www.coolermaster.com)

China - Cooler Master China  
Room 112, Building 9, No. 327, Songjin Road, Jinshanwei Town,  
Jinshan Dist., Shanghai City, China  
Tel: 400-9986-400

Europe - Cooler Master Europe B.V.  
Lodewijkstraat 1b, 5652AC Eindhoven, The Netherlands  
Tel: +31- (0)40-702-0900

North America - Cooler Master NA  
1 N Indian Hill Blvd Suite D200 Claremont, CA 91711 U.S.A.  
Tel: +1-888-624-5099

For the most updated information, please visit our official website:  
[www.coolermaster.com](http://www.coolermaster.com) /  
Cooler Master Support: <https://account.coolermaster.com/>



**Cooler Master Europe B.V.**  
**Lodewijkstraat 1b, 5652AC Eindhoven,**  
**the Netherlands**  
**[consumer\\_care@coolermaster.eu](mailto:consumer_care@coolermaster.eu)**



Ver 1.0 2025/06

©2025 Cooler Master Technology Inc. All Rights Reserved. All trademarks are registered to their respective owners.