






1




2





3




4






5




6



Internet




UniFi Cloud
Gateway



UniFi Switching




SuperLink
Gateway








7










Water Detection Sensor Cable











CR123A Battery





If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

