

#### Overview

The LVC-S is a 3-button (Up, Stop, Down) wall switch which controls an LVC-IV (low-voltage control module). The buttons are square. The 2 3/4" x 4 1/2" cover plate is plastic, and finished white.

It fits a single-gang box. Installer supplied wire leads (18-24 Gauge).

There are screw terminals on the back for Down, Common, and Up.

#### Uses

Up, Down and Stop control of an LVC-IV (low-voltage control module) via wall switch.

#### Compatibility

The LVC-S can be used with the LVC-IV. Other controls may be connected to the LVC-IV simultaneously:



	NAME	DESCRIPTION	PART NO.
COMPATIBLE COMPONENTS:	<b>LVC-S</b>	Low-Voltage Wall Switch.	<b>121225</b>
	More than one LVC-S can control a single LVC-IV	Low-Voltage Wall Switch w/ Locking Cover	<b>121232</b>
	<b>WRT / R</b>	Radio Frequency Remote Control	<b>Antenna Built-In</b>
	<b>IRT / R</b>	Infrared Remote Control Package	<b>Connects to IR Port</b>
	<b>SP-KSM</b>	3-position Momentary Key Switch (Please Note: 'Stop' won't work).	<b>121022</b>
	<b>Auxiliary Control</b>	Control systems employing "dry" contacts.	<b>By Others</b>

<b>CONTACTS:</b>	<b>Three individual Single Pole, Single Throw contacts (On/Off).</b> Momentary action. Latching contacts are part of the LVC-IV.
------------------	---

<b>RATING:</b>	<b>10V 25mA</b>
----------------	-----------------

