

INSTRUCTION SHEET

RM-LCD-MX

RM-LCD SERIES



THANK YOU

Thank you for purchasing the RM-LCD Series LCD Rackmount. Please read these instructions thoroughly before installing/assembling this product.

TABLE OF CONTENTS

RM-LCD-MV LCD SCREEN INSTALLATION.....	Page 2
RM-LCD-MK LCD SCREEN INSTALLATION.....	Page 3 - 5
RM-LCD-MT LCD SCREEN INSTALLATION.....	Page 5 - 6
POSITIONING MONITOR DEPTH.....	Page 6



Middle Atlantic Products

I-00372 Rev -

SUPPLIED HARDWARE (All Models)




(4) # 2 Phillips Head VESA Mounting Screws


NOTE: The center frame comes from the factory in the forward most position.

INSTALLATION OF LCD SCREEN (Model RM-LCD-MV)

1) Install monitor into VESA holes using provided screws.



VESA 75 MOUNTING HOLES



VESA 100 MOUNTING HOLES

INSTALLATION OF LCD SCREEN (Model RM-LCD-MK)

NOTE: The LCD screen can be mounted using two methods.

METHOD ONE

- 1) Detach the VESA mount from the frame by removing the six 1/2" bolts and wing nuts.
- 2) Attach monitor to corresponding VESA holes with provided screws.
- 3) Reattach the VESA mount/monitor to the frame using previously removed bolts and nuts.

METHOD TWO

- 1) Tilt the top of the mount all the way forward. (FIGURE A)




FIGURE A

- 2) Install two provided mounting screws into the bottom of the monitor. (FIGURE B)



FIGURE B

INSTALLATION OF LCD SCREEN (Model RM-LCD-MK Continued)

3) Rotate the monitor 180 degrees (the monitor/VESA mount rotates left and right). (FIGURE C)




FIGURE C

4) Install the other two provided mounting screws into the top of the monitor. (FIGURE D)



FIGURE D

INSTALLATION OF LCD SCREEN (Model RM-LCD-MK Continued)

5) Adjust the monitor to the desired position.

6) Using a 1/2" wrench, tighten the bolts that control vertical and horizontal positioning. (FIGURE E)




FIGURE E


INSTALLATION OF LCD SCREEN (Model RM-LCD-MT)

- 1) Install the monitor to the VESA mount on the end of the arm using provided screws. (FIGURE A)
The monitor can be installed by removing the arm (FIGURE B - Page 6) or while the arm is attached.



FIGURE A

INSTALLATION OF LCD SCREEN (Model RM-LCD-MT Continued)




(Remove arm by lifting straight up)

FIGURE B

POSITIONING MONITOR DEPTH

- 1) Determine the desired depth of the monitor. Loosen the 9 mm bolts (2 per side) and position the frame/monitor. Tighten the bolts and mount the unit in the enclosure.



WARRANTY

Middle Atlantic Products, Inc. (the "Company") warrants the RM-LCD-MV to be free from defects in material or workmanship under normal use and conditions for the lifetime of the product, three (3) years for the RM-LCD-MK/RM-LCD-MT from shipment from the company.

The Company's entire liability to the purchaser, and the purchaser's (or any other party's) sole and exclusive remedy, under this warranty shall be limited, at the Company's option, to either (a) return of and refund of the price paid for, or (b) repair or replacement at the Company's factory of the products purchased, or any part or parts thereof, which the Company has determined to be defective after inspection thereof at the Company's factory. This warranty does not cover damage due to acts of God, accident, misuse, abuse or negligence by parties other than the Company, or any modification or alteration of the products. In addition, this warranty does not cover damage due to improper handling, assembly, installation or maintenance.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF THE PRODUCTS PURCHASED, EVEN IF THE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE COMPANY'S LIABILITY TO THE PURCHASER (OR ANY OTHER PARTY) HEREUNDER, IF ANY, SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE PRODUCTS PAID TO THE COMPANY.

Corporate Headquarters

Corporate Voice 973-839-1011 - Fax 973-839-1976 / International Voice +1 973-839-8821 - Fax +1 973-839-4982
middleatlantic.com - info@middleatlantic.com

Middle Atlantic Canada

Voice 613-836-2501 - Fax 613-836-2690 / middleatlantic.ca - contactcanada@middleatlantic.com

Factory Distribution

USA: NJ - CA - IL Canada: ON - BC

At Middle Atlantic Products we are always listening. Your comments are welcome.

Middle Atlantic Products is an ISO 9001 Registered Company.