


For spare parts  
R114952

refer to user manual  
"ADJUSTING BRAKE  
FORCE"



R114968



R114956



R545,07



R114967



included in  
R1149102

R114938



included in  
R1149102




R3,2336  
Exagonal 3mm




R114999  
set of 3

R1149102



included in  
R1149102

R114952



art. MVASPRM

included in  
R1149102



R114944

1149102L  
assembled leg with laser

RE114943




**BOX**

FOR MVTTWINFC  
see RI,500,18,15 set of 4

FOR MVTTWINFCUS  
see RI,500,18,16 set of 4


LEG MAINTENANCE SPARE PARTS AT PAGE 2:  
MANFROTTO SERVICE CENTER PROVIDE  
PROFESSIONAL MAINTENANCE ON THE LEG.  
PLEASE REFER TO THEM






**Manfrotto**  
**Imagine More**


ART. MVTTWINFA  
ART. MVTTWINFAUS




RE114987




R1149111  
R1159111L with laser




R114928T




R114942




R114935



R114926



R114981



R114941Z



R114964

FOR ANY MAINTENANCE ON THE LEG  
IS HIGHLY RECOMMENDED TO REFER TO A  
MANFROTTO SERVICE CENTER