





Dell Premier Multi-Device Wireless Keyboard and Mouse

KM7321W

Quick Start Guide




Dell.com/support/KM7321W




1


1



2




3



4



5




2


1



2




3




2




2




3




3



2



3




© 2020-2022 Dell Inc. or its subsidiaries. 2022-06




0N9V3A02

3


1




2



3




4



4


1



2




2



3



3



3



www.dell.com/support/dpem



www.dell.com/support
www.dell.com/regulatory_compliance