

## Fitting chart – Tripod bags for video supports

VIDEO SUPPORTS	TRIPOD BAGS								
	MB MBAG60N	MB MBAG70N	MB MBAG75N	MB MBAG75PN	MB MBAG80N	MB MBAG80PN	MB MBAG90PN	MB MBAG100PN	MB MBAG120PN
MVH500AH,755XBK	73				•	•			
MVH500AH,755XCX3	73				•	•			
MVK500M	72				•	•			
MVK500AQ	72				•	•			
MVK500C	85						•		
MVK502C-1	87,5							•	
MVK502AQ	73,4				•	•			
MVK502AM-1	75				•	•			
MVH502A,546BK-1	83						•		
MVH502A,546GB-1	83						•		
504HD,536K	85,5							•	
MVK504AQ	73				•	•			
504HD,535K	88							•	
504HD,546BK	84							•	
504HD,546GBK	84							•	
509HD,536K	87							•	
509HD,545BK	84							•	
509HD,545GBK	84							•	
526,536K	86							•	
526,545BK	84							•	
526,545GBK	84							•	
526,528XBK	114								•
MVM250A	67	•							
MVM500A	77				•	•			
MVM450A	77				•	•			
560B-1	65,5	•							
562B-1	69	•							

\* The information contained in this fitting chart is for general information purposes only. The information is provided by Manfrotto and while we endeavor to keep the information up to date and correct, we make no representations or warranties of any kind, express or implied, about the completeness, accuracy, reliability, suitability or availability with respect to the website or the information, products, dimensions. Any reliance you place on such information is therefore strictly at your own risk. We suggest you to visit our dealers and check dimensions with your gears to make sure it fits your need.