

www.datavideo.com

# **Table of Contents**

FCC COMPLIANCE STATEMENT	4
WARNINGS AND PRECAUTIONS	4
WARRANTY	6
Standard Warranty Three Year Warranty	
DISPOSAL	7
1. INTRODUCTION	8
2. CONNECTIONS AND CONTROLS	9
2.1Front Panel 2.2 Rear Panel	
3. FIRMWARE UPDATE	12
3.1 System Connection 3.2 Checking the Firmware Version 3.3 Updating the Firmware	14
5. SPECIFICATIONS	21
SERVICE AND SUPPORT	24

#### **Disclaimer of Product & Services**

The information offered in this instruction manual is intended as a guide only. At all times, Datavideo Technologies will try to give correct, complete and suitable information. However, Datavideo Technologies cannot exclude that some information in this manual, from time to time, may not be correct or may be incomplete. This manual may contain typing errors, omissions or incorrect information. Datavideo Technologies always recommend that you double check the information in this document for accuracy before making any purchase decision or using the product. Datavideo Technologies is not responsible for any omissions or errors, or for any subsequent loss or damage caused by using the information contained within this manual. Further advice on the content of this manual or on the product can be obtained by contacting your local Datavideo Office or dealer.

# FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



# Warnings and Precautions

- 1. Read all of these warnings and save them for later reference.
- 2. Follow all warnings and instructions marked on this unit.
- 3. Unplug this unit from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 4. Do not use this unit in or near water.
- 5. Do not place this unit on an unstable cart, stand, or table. The unit may fall, causing serious damage.
- 6. Slots and openings on the cabinet top, back, and bottom are provided for ventilation. To ensure safe and reliable operation of this unit, and to protect it from overheating, do not block or cover these openings. Do not place this unit on a bed, sofa, rug, or similar surface, as the ventilation openings on the bottom of the cabinet will be blocked. This unit should never be placed near or over a heat register or radiator. This unit should not be placed in a built-in installation unless proper ventilation is provided.
- This product should only be operated from the type of power source indicated on the marking label of the AC adapter. If you are not sure of the type of power available, consult your Datavideo dealer or your local power company.
- Do not allow anything to rest on the power cord. Do not locate this unit where the power cord will be walked on, rolled over, or otherwise stressed.
- 9. If an extension cord must be used with this unit, make sure that the total of the ampere ratings on the products plugged into the extension cord do not exceed the extension cord rating.

- 10. Make sure that the total amperes of all the units that are plugged into a single wall outlet do not exceed 15 amperes.
- 11. Never push objects of any kind into this unit through the cabinet ventilation slots, as they may touch dangerous voltage points or short out parts that could result in risk of fire or electric shock. Never spill liquid of any kind onto or into this unit.
- 12. Except as specifically explained elsewhere in this manual, do not attempt to service this product yourself. Opening or removing covers that are marked "Do Not Remove" may expose you to dangerous voltage points or other risks, and will void your warranty. Refer all service issues to qualified service personnel.
- 13. Unplug this product from the wall outlet and refer to qualified service personnel under the following conditions:
  - a. When the power cord is damaged or frayed;
  - b. When liquid has spilled into the unit;
  - c. When the product has been exposed to rain or water;
  - d. When the product does not operate normally under normal operating conditions. Adjust only those controls that are covered by the operating instructions in this manual; improper adjustment of other controls may result in damage to the unit and may often require extensive work by a qualified technician to restore the unit to normal operation;
  - e. When the product has been dropped or the cabinet has been damaged;
  - f. When the product exhibits a distinct change in performance, indicating a need for service.

# Warranty Standard Warranty

- Datavideo equipment are guaranteed against any manufacturing defects for one year from the date of purchase.
- The original purchase invoice or other documentary evidence should be supplied at the time of any request for repair under warranty.
- The product warranty period beings on the purchase date. If the purchase date is unknown, the product warranty period begins on the thirtieth day after shipment from a Datavideo office.
- Damage caused by accident, misuse, unauthorized repairs, sand, grit or water is not covered under warranty.
- Viruses and malware infections on the computer systems are not covered under warranty.
- Any errors that are caused by unauthorized third-party software installations, which are not required by our computer systems, are not covered under warranty.
- All mail or transportation costs including insurance are at the expense of the owner.
- All other claims of any nature are not covered.
- Cables and batteries are not covered under warranty.
- Warranty only valid in the country or region of purchase.
- Your statutory rights are not affected.

# **Three Year Warranty**

- All Datavideo products purchased after July 1st, 2017 are qualified for a free two years extension to the standard warranty, providing the product is registered with Datavideo within 30 days of purchase.
- Certain parts with limited lifetime expectancy such as LCD panels, DVD drives, Hard Drive, Solid State Drive, SD Card, USB Thumb Drive, Lighting, Camera module, PCIe Card are covered for 1 year.
- The three-year warranty must be registered on Datavideo's official website or with your local Datavideo office or one of its authorized distributors within 30 days of purchase.

### Disposal



#### For EU Customers only - WEEE Marking

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve

natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

# 1. Introduction

The DAC-8P4K Converter converts 12G-SDI in resolutions up to 4K50/60to 4K HDMI, it is easy to connect the 4K HDMI signal devices and professional 12G-SDI video equipment.

Featuring SDI input and both an SDI and an HDMI output, the audio is deembedded from the SDI input, and available in the HDMI output and analog audio output.

The DAC-8P4K Converter is useful for a variety of broadcast and professional AV applications.

### Features

- Supports up to DCI 4K (4096 x 2160) and UHD 4K (3840 x 2160)
- 12G-SDI input and loop-thru output
- Supports HDMI 2.0 to 18 Gbps Video bandwidth
- Supports Re-Clocking
- Provides Additional 2-Channel RCA Analog Audio Output
- Supports Automatic Input Signal Detection
- Supports HDMI Deep Color function.
- Aluminum appearance design, which is rugged and durable.

# 2. Connections and Controls



### 2.1Front Panel

	<ul> <li>12G-SDI HD/SD - SDI Input &amp; Output (bypass)</li> <li>SDI provides video signals for professional applications and allows long distance signal transmission.</li> <li>IN: 12G HD/SD-SDI Input.</li> <li>LOOP THRU: 12G-HD/SD-SDI Loop Through Output.</li> <li>Signal LED Indicator: When the input signal is connected, this indicator will light up.</li> </ul>
F/W UPGRADE	<b>F/W UPGRADE</b> This USB Type C interface is used for firmware update only.

### 2.2 Rear Panel



DC IN Socket Please connect the supplied 12V DC adapter to this interface. The connection can be secured by screwing the outer fastening ring of the DC In plug to the socket. Power LED Indicator If the DC IN 12V power is connected, this indicator will light up.
<b>4K HDMI OUT</b> This is the 4K HDMI OUT interface.



### AUDIO OUT RCA Output

Two channels of Unbalanced L / R Audio input. The audio signal can be de-embedded from the SDI input signal and then be outputted from this AUDIO OUT interface.

# 3. Firmware Update

### **Firmware Update Procedure**

### DAC-8P 4K

This document provides procedures for updating the DAC-8P 4K 4K SDI to HDMI Converter.

#### Updating the DAC-8P 4K 4K SDI to HDMI Converter Firmware What items you should prepare before updating the firmware

• The latest DAC-8P 4K firmware zip file x 1

The latest firmware zip file can be downloaded from the DAC-8P 4K product page of the Datavideo official website

https://www.datavideo.com/product/DAC-8P%204K . After the downloaded firmware zip file is unzipped, you can see one firmware file.

Converter firmware file : CV-315KZ-DV-R3\_220314.bin

- DAC-8P 4K main unit x 1
- USB Type-C to USB Type-A adapter cable x 1
- Firmware update tool x 1
- DC 12V power adapter x 1
- Notebook PC x 1

This document describes how to perform firmware update on a Windows computer.

### **3.1 System Connection**



**Checking the Firmware Version** 

page 14 Page 16

Updating the Firmware

### **3.2 Checking the Firmware Version**

1. Please use a 12V power adapter to connect to the DC IN 12V power interface of the DAC-8P 4K.

2. Please use a USB Type-C to USB Type-A adapter cable to connect from the USB Type-C interface of the DAC-8P 4K to the USB Type A interface of your notebook PC or PC.

3. Please open the downloaded firmware update tool "DAC-TOOL.exe".

DAC-8PA / DAC-8P 4K	C DAC-9P 4K	VID: 5566	PID: 5566	
W Revision:	Read			
Firmware MCU				
	Г			
Burn	Cancel			
iudio Level				
SMPTE	EBU			

4. Please select the DAC-8PA/DAC-8P 4K option.

📓 FirmwareTool v1.06	×
C DAC-8P-4 / DAC-8P-4K C DAC-9P-4K VID: 5566 PID: 5566	
Firmware MCU	
C:/	
Burn Cancel	
Audio Level	
SMP1E EBU	

5. Please press the "Read" button next to the "FW Revision" column for

reading the current firmware version.

ImmareTool V1.06         >           © DAC-8P4 / DAC-9P4K         VD:         5566         PD:         5566           FV Revision:	
Firmware MCU	
FW Revision: Read	
Burn Cancel	

FirmwareTool v1.06	>
DAC-8PA / DAC-8P 4K C DAC-9P 4K VD; 5566 PD; 5566      FW Revision: 2022.03.14.A Read	
Firmware MCU	
@ DAC-8PA / DAC-8P 4K         C DAC-9P 4K         VD:         5566         PD:         5566           FW Revision:         [2022.03.14.A]         Reed	
Burn Cancel	
	-

#### 3.3 Updating the Firmware

1. Please use a 12V power adapter to connect to the DC IN 12V power interface of the DAC-8P 4K.

2. Please use a USB Type-C to USB Type-A adapter cable to connect from the USB Type-C interface of the DAC-8P 4K to the USB Type-A interface of your notebook PC or PC.

3. Please open the downloaded firmware update tool "DAC-TOOL.exe".

FirmwareTool v1.06     OAC-8PA / DAC-8P4K C DAC-9P4K v	ID: 5566 PID: 5566
FW Revision: Read	ID: 1200 NID: 1200
Firmware MCU	
C:\	
Burn Cancel	
Audio Level	
SMPTE EBU	

4. Please select the DAC-8PA/DAC-8P 4K option.

FirmwareTool v1.06	×
© DAC-8PA / DAC-8P 4K         C         DAC-9P 4K         VZD:         5566           FW Revision:         Read	
C DAC-8PA / DAC-8P 4K         C DAC-8P 4K         VEI:         5566         PID:         5566           FW Revision:         Read         Read         Filmware MCU	
-Audio Level	44 C DAC-994K V2D; 5566 P2D; 5566 Read
SMPTE EBU	

5. Please click the button next to the "Firmware MCU" to select your

downloaded firmware file and then press the "Open" button.

FirmwareTool v1.06	)
C-8P-4 / DAC-8P-4K         VID:         5556         PID:         5556           sion:         Read	
Burn Cancel	
Audo Level EBU	

lder					2
^	Name	Date modified Type Size 315KZ-DV-R3_220314.bin 3/14/2022 8:44 AM BIN File 23			
	CV-315KZ-DV-R3_220314.bin	3/14/2022 8:44 AM	BIN File		23
~ <					>
name:		BIN	(*.BIN)	~	
			Open	Cancel	

### 6. You can see that the firmware file is selected, please press the "Burn"

button.

FirmwareTool v1.06     DAC-8PA / DAC-8P	4K C DAC-9P 4K VID: 5566 PID: 5566	
FW Revision:	Read	
	1100	
Firmware MCU	tng2(Firmware)Firmware Release)DAC-8P 4K(DAC-8P 4K & DAC-9P 4K FW Too	
Audio Level		
SMPTE	EBU	

7. You will see a reminder to remind you to reboot DAC-8P 4K, please unplug

and replug the power for your DAC-8P 4K.

FirmwareTool v1.06     O DAC-8PA K C DAC-9P 4K VID: 5566     PID: 5566	
FW Revision: Read	
Firmware MCU [/\192.168.1.60\marketing2\Firmware\Firmware Release\DAC-8P 4K\DAC-8P 4K & DAC-9P 4K FW Too	1
Burn Cancel	
Audio Level	
SMPTE EBU	
	-

8. After the DAC-8P 4K is power-cycled, the firmware update procedure will

be started automatically. After the progress bar reaches 100%, the firmware is

updated successfully.

HirmwareTool v1.06	×
ODAC-8PA ( DAC-8P 4K  DAC-8P 4K  VE: 5566  PE: 5566     PVX Revision:	
[\]192.168.1.69/marketing2/Firmware Release(JAC-6P 4K_DAC-6P 4K_& DAC-9P 4K_FW Too            Burn         Cancel         Firmware Updeta Successt	
Audo Level EBU	



All measurements in millimeters (mm)

# 5. Specifications

Model Name	DAC-8P 4K
Product Name	4K SDI to HDMI Converter
Conversion	12G-SDI to HDMI 2.0
Video Input	12G-SDI x 1
Loop Through	1
Video Output	1x HDMI 2.0 with embedded Audio
Audio Input	SDI embedded audio, 24-bit, 16-channel
Audio Output	RCA x 2 (Unbalanced Audio L/R) HDMI embedded audio, 24-bit, 8-channel
Supported Video Input Formats	4096x2160p: 60/59.94/50/30/29.97/25/24/23.98 3840x2160p: 60/59.94/50/30/29.97/25/24/23.98 1080p: 60/59.94/50/30/29.97/25/24/23.98 1080i: 60/59.94/50, 720p: 60/59.94/50

Output Resolutions	Automatically matches the HD, 3G and 12G SDI video input
Equalizer	Yes
Reclock	Yes
SDI Cable Drive	Yes
Updates and Configuration	USB Type C x 1
Dimension (LxWxH)	112 x 85 x 45 mm
Weight	0.3 kg
Operating Temp. Range	0~40 °C
Power	DC 12V, 8.64W

## Note

# Service & Support

It is our goal to make your products ownership a satisfying experience. Our supporting staff is available to assist you in setting up and operating your system. Please refer to our web site www.datavideo.com for answers to common questions, support requests or contact your local office below.

https://www.datavideo.com/product/DAC-8P%204K





@DatavideoUSA @DatavideoIndia2016 @DatavideoEMEA @Datavideojapan @DatavideoTaiwan @DatavideoLatam @DatavideoAsia @DatavideoBrasil



@Datavideo @Datavideo\_EMEA @Datavideo\_Taiwan



@DatavideoUSA @DVTWDVCN

5

@DatavideoUSA

@DatavideoEurope

All the trademarks are the properties of their respective owners. Datavideo Technologies Co., Ltd. All rights reserved 2020