





1








2



3










Power on and initialize (up to 2.5 min).

4




5





6








7





8








9




10






- | | | |
|---|----------------|---|
|  | Steady White | Device ready for setup. |
|  | Steady Blue | Setup successful. Continue at mobility.ui.com . |
|  | Flashing White | Unable to activate SIM. Check SIM PIN and APN. |
|  | Flashing Blue | Unable to connect to the LTE network.
Relocate the device or contact your ISP. |


For more details please visit mobility.ui.com/doc/led.








1



2







If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

©2024 Ubiquiti Inc. All rights reserved. Ubiquiti, the Ubiquiti U logo, and UniFi are trademarks or registered trademarks of Ubiquiti Inc. in the United States and in other countries.