

# INSTALLATION INSTRUCTIONS

## Product

**7160-1306 & 7160-1306-01**  
**Scanner Pocket Mount**

## Revision

Rev.A

## Form

INST-874

Printing Spec:PS-001


The following instruction sheet is for mounting the scanner pocket mounts on various fork trucks. 7160-1306 (with the short back plate) will fit on rectangular overhead guard legs 1.00" to 2.50" wide while the 7160-1306-01 (with large back plate) will fit on rectangular overhead guard legs 2.50" to 5.00" wide.

The assembly attaches to the rectangular overhead guard leg on the fork truck or can be used in conjunction with roll formed mounting brackets like GJ# 7160-0418 for trucks with roll formed overhead guard legs.

The scanner pocket can hold a scanner with a head thickness of 2.50" high x 4.50" wide. The scanner pocket width is adjustable to accommodate scanners 3.50" to 4.50" wide. The pocket mounting angle is also adjustable from parallel to the overhead guard leg to 60 deg. downward away from the overhead guard leg.

The scanner pocket has multiple square holes on each side of the pocket for a vast array of mounting locations so each user can best position the mount as they see fit.

The pocket mounting bracket can also be positioned forward for backward to adjust the location of the scanner pocket on the vehicle. See below for various mounting options.



### Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufacturer's specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

# 7160-1306

7160-1306 (with small back plate) is shown below in various mounting positions. Attach the mounting bracket to the overhead guard leg with the short back plate found in hardware bag 7120-0553. Postion the 3/8" carriage bolts as close to the overhead guard leg as possible to help prevent the mounting bracket from bending during installation. Then attach the scanner pocket to the mounting bracket in the desired position which best fits the end user. Use the 1/4" x 3/4" carriage bolts, flat washers, and nylock cap nuts found in hardware bag 7120-0885 to attach the pocket to the mounting bracket. The width of the scanner pocket can be adjusted by loosening the (3) cap nuts on the top side of the pocket. Adjust the pocket to the desired fit and retighten the cap nuts.



cap nuts to adjust width



# 7160-1306-01

7160-1306-01 (with large back plate) is shown below in various mounting positions. Attach the mounting bracket to the overhead guard leg with the large back plate found in hardware bag 7120-0555. Position the 3/8" carriage bolts as close to the overhead guard leg as possible to help prevent the mounting bracket from bending during installation. Then attach the scanner pocket to the mounting bracket in the desired position which best fits the end user. Use the 1/4" x 3/4" carriage bolts, flat washers, and nylock cap nuts found in hardware bag 7120-0885 to attach the pocket to the mounting bracket. The width of the scanner pocket can be adjusted by loosening the (3) cap nuts on the top side of the pocket. Adjust the pocket to the desired fit and retighten the cap nuts.



cap nuts to adjust width

